

## 003 GATE OVERRIDE PROCEDURE:

This procedure details the method in which to override an automatic gate in the event of an emergency.

1. Identify automatic gate keyswitch module (see below):



2. Insert 003 key into switch and turn until the unit clicks.
3. If the gate has power, the gate will automatically open.
4. If the gate has no power, the gate motor can be put into a manual operation mode by completing the following steps:
  - a. Insert gate motor key into lock cylinder on gate motor housing.
  - b. Open access panel.
  - c. Locate the internal, circular clutch knob.
  - d. Turn clutch knob anti-clockwise 5 turns.
  - e. Gate should now be in manual mode and able to be operated by hand.
  - f. **CAUTION:** large gates on inclines will start to move on their own once the clutch is disengaged. It is advised to have at least two competent people holding the gate at all times while in manual mode. And the gate should be chained open or closed at all times.

